


2021 Ram Promaster

Tire Service Kit Components and Operation



Tire Service Kit Components

- 1. Power Button
- 2. Mode Select Knob
- 3. Sealant Hose (Clear)
- 4. Sealant Bottle
- 5. Air Pump Hose (Black)
- 6. Sealant Bottle Release Button
- 7. Power Plug
- 8. Pressure Gauge
- 9. Deflation Button

The Tire Service Kit is located under the passenger seat or the driver side door.