

## 2022 Ford E-Transit

Spare Tire Change



Before jacking the vehicle, ensure it is on solid level ground.

Place in PARK and set PARKING BRAKE



Jack and Tool Kit are located under passenger seat in the step well



Remove rubber plug and lower spare tire with square drive on the long end of lug nut wrench



Remove retainer from spare tire bracket to allow complete removal of spare tire

Before jacking the vehicle chock wheel at diagonally opposing wheel Example – A flat at the Front Driver Tire, Chock Rear Passenger Tire



## Before jacking the vehicle chock wheel at diagonally opposing wheel Example – A flat at the Front Driver Tire, Chock Rear Passenger Tire

Only jack vehicle at recommended jacking points. Lifting by front suspension components may result in damage.

High Voltage Battery Pack is inside frame rails, center of vehicle.

Verify jack placement before lifting vehicle.



Front jacking location, directly behind tire, bolted body brackets



Rear jacking location, in front of rear tire, outer bush of suspension arm reinforced pad