

# 2021 Ram Promaster

## Tire Service Kit Storage

---



The Tire Service Kit is located under the passenger seat or the driver side door.